


PLC with analog input and output instructions

1、Analog reading instruction




● 模拟量模块的模拟量输入值的读取指令。

(m1) : Module number, the host is set to K0

(m2) : Analog input channel number.
K0-K5 (对应AI1-6)

(D) : Read data stored instantaneous value to D0
Save the module to read Zimo nil value

2、Analog Output command



● 用于向模拟量模块写入数字值的指令

(m1) : Module number, the host is set to K0


(m2) : Analog output channel number
K0-K1

(D) : Write data
Value specifies the write analog modules (0-4095)

Clock module description:

Set the clock when the M8015 should be set, Restore run M8015 reset. D8018 for the year, D8017 for the month, D8016 for the day, D8019 for weeks, D8015 for hours, D8014 for minutes, D8013 for seconds. Can use the clock data to read the instruction TRD to read the clock data to the general register, Or use the clock to write to the instruction TWR to modify the clock, using this instruction does not need to set the bit M8015.

PID arithmetic instructions:



This directive is used to carry out PID control of the PID computing program.

S1: set the target value; S2: the current value (the value of feedback back);

S3:PID control parameters, occupy the S3 start of the 9 consecutive D registers.

S3 channel number for PID; S3+1 ratio coefficient KP; S3+2 for integral coefficient KI; S3+3 is the differential coefficient KD; The error coefficient S3+4 is KE, PID processing is performed only if the error is greater than this value; S3+5 output upper limit value PMAX; S3+6 output lower limit value PMIN; S3+7 backup; S3+8 standby; D: control value output;

Automatic communication between CAN hosts

Station No.	Data exchange area	Station No.	Data exchange area	Station No.	Data exchange area
0	D3500-3515	8		16	
1	D3516-3531	9		17	
2	D3532-3547	10		18	
3	D3548-3563	11		19	
4	D3564-3579	12		20	
5	D3580-D359	13		21	
6		14		22	
7		15		23	

CAN communication example:

LD M8002 The implementation of a power // said

M8181 //CAN SET host communication

MOV K0 D8121 // station number is 0

Station number 0 PLC as long as the D3500-3515 to write data, Other station number PLC as long as the reading of their own D3500-3515

The data is equal to the D3500-3515 data read station number 0. Station number 0 PLC to read their own D3516-3531 data, etc.

D3516-3531 data read station No. 1.

CAN communication between the host of the PLC and other CAN_H connected to the CAN_H,CAN_L is connected with other CAN_L PLC, and the transmission distance

is far., To connect the terminal resistance on the PLC board, The corresponding code switch (the upper left corner of the 2) to play in the ON bit.

9、RS232 communication port (S terminal 8 core): default communication protocol: FX3u, 38400,7, E, 1

The baud rate can be changed via S2 DIP switch # 3:

State Dial switch	OFF	ON
No. 1	SPI extension 16	SPI extension 32
No. 2	SPI extension is valid	CS5532 extension is
No. 3	9600	38400
No. 4	Factory trial	

10、Serial data transmission:

\

Special register	explain	Special relay	explain
White 3 pin RS485 communication port			
D8120	RS485 Communication format definition	M8121	When the data is sent, the data is sent, and the automatic reset is sent.
D8121	RS485 communication station number setting	M8122	Send a request, when the M8122 position, once the communication port is free to start sending data, start the automatic reset
D8122	Send data surplus	M8123	When the data is received, the data can be automatically set after receiving a frame data, and the user should reset the position after receiving the data
		M8124	The data receiving center, receiving the data reduction
White 3 pin RS232 communication port			
D8126	RS232 communication	M8125	When the data is sent, the data is sent, and the automatic reset is sent.
D8127	RS232 communication station number setting	M8126	Send a request, when the M8126 position, once the communication port is free to start sending data, start the automatic reset
D8128	Send data surplus	M8127	When the data is received, the data can be automatically set after receiving a frame data, and the user should reset the position after receiving the data
		M8128	The data receiving center, receiving the data reduction

M8129: Communication timeout tag, when the host issued a command, from the time the machine did not respond to the M8029, D8129 will set the bit


The corresponding communication

No.	name	content	
		0 (位 OFF)	1 (位 ON)
B0	Data length	7	8
B1	Parity bit	b2 b1	
B2		(0, 0) : No verification (0, 1) : Odd ODD	
B3	Stop bit	1	2
B4	Transfer ratebps	b7 b6 b5 b4 b7 b6 b5 b4	
B5		{0, 0, 1, 1}: 300 {0, 1, 1, 1}: 4800	
B6		{0, 1, 0, 0}: 600 {1, 0, 0, 0}: 9600	
B7		{0, 1, 0, 1}: 1200 {1, 0, 0, 1}: 19200	
B8	Start symbol	nothing	yes (D8124)
B9	Terminator	nothing	yes (D8125)
B10	Do not use		
<u>D11</u>			
B12	communication protocol	B15 b14 b13 b12	
B13		{0, 0, 0, 0}: MITSUBISHI FX2N protocol (from machine)	
B14		{0, 1, 0, 0}: MODBUS RTU (from machine)	
B15		{1, 0, 0, 0}: RTU MODBUS (host, IVRD, IVWR instruction) {1, 1, 0, 0}: Free communication (RS instruction, with CCD check)	

When M8120 reset, the implementation of RS, the parameters are for the RS485 port, when the M8120 set, the implementation of RS, the parameters are for the RS232 port.



- 数据的传送格式可以通过后面所述的特殊数据寄存器D8120设定。
RS 指令驱动时即使改变D8120的设定，实际上也不接受。
- 在不进行发送的系统中，请将数据发送点数设定为“KO”。
或在不进行接受的系统中，接收点数设定为“KO”。




CCD instruction:

S specified by the n components as the starting point of the data, the sum of their data and CRC calibration data Stored in D. with D.+2, D.+3. This example and the check on the D0, CRC check in D3, D2.

十一、Communication with frequency conversion or instrument::

The corresponding communication




D0 for reading the station number (high 8) and the command code (low 8), such as the value of H103 D0, is the number of stations

1, read the order 3。 D1 to read the data address, D2 the first address of the data returned by the receiving frequency conversion or instrument., Receive data, such as channel 0, M8123 will set the bit。 H1, High 8 bit channel, low 8 bit read a number。 Through the channel 0 (485 channels), read the 1 data. If the bit H101, is through the channel (RS232 channel) 1 to read the 1 data.

write in

D0 to write the number of stations (high 8) and command code (low 8), Such as the



value of H106 is D0, that is, station number 1, write a single data command 6 D1 for the data to be written to the address, D2 to write the first address of the frequency conversion or instrumentation data。 H1, high 8 bit for the channel, low 8 bit write a number。 Through the channel 0 (485 channels), write 1 data。 If it is H101, is through the channel (RS232 channel) 1 to write 1 data。 Write complete M8122 automatic reset.

Twelve, high speed count: SPD instruction (support X0-5), if the encoder is a circle of 360 pulses, 2 times the 720 pulse can be obtained, 4 times, then you can get 1440 pulses, thus improving the resolution of the encoder.

Count input	Single phase meter number	Up and down Number direction switch	Count input	Single phase 2 frequency Counter number	Up and down Number direction switch
X0	C235	M8235	X0	C241	M8241
X1	C236	M8236	X1	C242	M8242
X2	C237	M8237	X2	C243	M8243

X3	C238	M8238	X3	C244	M8244
X4	C239	M8239	X4	C245	M8245
X5	C240	M8240	X5	C246	M8246
Count input	Counter		Count input	Dual phase 4	Up and down
		direction (only)		Counter number	Read)
		Read)			
X0 (A 相)	C250	M8250	X0 (A 相)	C253	M8253
X1 (B 相)			X1 (B 相)		
X2 (A 相)	C251	M8251	X2 (A 相)	C254	M8254
X3 (B 相)			X3 (B 相)		
X4 (A 相)	C252	M8252	X4 (A 相)	C255	M8255
X5 (B 相)			X5 (B 相)		

C247 (X0, X1), C248 (X2, X3), 249 (X6, X7) for the non double phase counter.

13 、 High speed pulse and pulse width modulation : Support and 8 pulse rushed out of the Y0-7 (PLSY, PLSV, PLSR, DRVA, DRVI, DSZR, ZRN, DVIT) or 6 way pulse width modulation Y0-5 (PWM), frequency 100K.

pulse	Number of output pulses	Output tag	Pulse disabled	Minimum output frequency	Acceleration / deceleration	DSZ R, DVIT	The DVIT interrupt	Origin return speed	OPR creep speed	ZRN Number of
Y0	D8132	M8147	M8141	D8144	D8145	M808	D8080	D8220	D8090	D807
Y1	D8134	M8148	M8142	D8146	D8147	M808	D8081	D8221	D8091	D807
Y2	D8136	M8149	M8143	D8148	D8149	M808	D8082	D8222	D8092	D807
Y3	D8138	M8150	M8144	D8150	D8151	M808	D8083	D8223	D8093	D807
Y4	D8140	M8151	M8145	D8152	D8153	M808	D8084	D8224	D8094	D807
Y5	D8142	M8152	M8146	D8154	D8155	M808	D8085	D8225	D8095	D807
Y6	D8166	M8153	M8155	D8156	D8157	M808	D8086	D8226	D8096	D807
Y7	D8168	M8154	M8156	D8158	D8159	M808	D8087	D8227	D8097	D807

14、 Interrupt description:

1, external interrupt support X0-X5, the interrupt number as follows:

	Rising edge	Falling edge	Interrupt inhibit
X0	I0	I1	M8050
X1	I100	I101	M8051
X2	I200	I201	M8052
X3	I300	I301	M8053
X4	I400	I401	M8054
X5	I500	I501	M8055

2, Timer interrupt pointer to I600, interrupt disable time range I601 (1MS) -I699 (99MS) M8056。

3, Counter interrupt pointer

Pointer number	Interrupt inhibit
I10	M8059
I20	
I30	
I40	
I50	
I60	


15、Third party Programming Software Description: can be compatible with the programming software Developer7.8 GX or 8.52、8.86 Version, create a new project:




Set the program step to 8000 steps:



Online, transmission settings, set the baud rate and the communication port to download:



Enter the ladder diagram editing interface, write your program:



Download the program: select the program, according to the implementation of the start download

